

# **9" BLUETOOTH KEYBOARD CASE**

Compatible with D2-962G model

# Quick Start Guide ACK901AB

U.S Service Hotline: 1-888-863-0138
More support at <u>www.d2pad.info</u>



# Charge your Bluetooth Keyboard

Note: Please fully charge the Bluetooth Keyboard prior to use. Follow the below instructions to "pair" your devices on initial use. Your paired devices will make connections automatically every time you use them afterwards.

Tip: To extend the life of your battery between charges, turn off the Bluetooth function whenever you are not using it. You may also be required to turn off Bluetooth function in some locations. Bluetooth function will turn off when you switch to Airplane mode.



Option 2: Charge through computer USB port


# Connect to Bluetooth

# Step 1.

Turn on your Bluetooth Keyboard by switching the power button from OFF to ON.

## Step 2.

Turn on your tablet's Bluetooth function by going to Settings > Wireless & networks and slide the Bluetooth slider from OFF to ON.





### Step 3.

On the Bluetooth Keyboard, press and hold on the "Bluetooh Connect Button" for 3 seconds then release it. Make sure the blue LED light starts flashing.

# Step 4.

On the tablet, click on "Search for device" or "Scan" button and the tablet will take a moment to search for the Bluetooth Keyboard.

## Step 5.


Once the scan result list shows up, click on the device name (see figure A).

## Step 6.

Once connected, a dialog window will pop up (see figure B), please follow the instruction and type in the requested number on your Bluetooth Keyboard to complete the pairing action.

## Step 7.

"Connected to input device" will display on your tablet (see figure C) when the devices have successfully paired. Now you may use your Bluetooth Keyboard.



Step 5. figure A



Step 6. figure B



Step 6. figure C

#### Cautions:

- 1. Keep away from sharp objects.
- 2. Do not put heavy objects on the keyboard.
- 3. Keep away from heat or fire.
- 4. Keep away from oil and/or any chemical liquids.
- 5. You may use water, alcohol, or alcohol disinfectant to clean ONLY the keyboard's silicone part.

#### FAO:

If you are having trouble connecting to the Bluetooth Keyboard to your tablet, please check the following:

- 1. Check if your tablet's bluetooth function is operable.
- 2. After you've pressed the "Bluetooth Connect Button" for 3 seconds then released it, make sure the blue LED light is flashing
- 3. Make sure your Bluetooth Keyboard is within the effective range of 10 Meter from your tablet.
- 4. If your tablet is connected to other bluthtooth products, please double check if your tablet supports multiple bluetooth device connectivity.
- 5. Please check if the Bluetooth Keyboard's battery is fully charged.

#### Warranty

Digital 2<sup>™</sup> offers a 90 DAYS limited warranty covering the hardware of Digital 2<sup>™</sup> Tablet Accessories ("Product"), limited to those residing in the 48 continental United States and Canada.

Digital2<sup>™</sup> warrants the Product to be free from defects in materials and workmanship for NINETY (90) days, as sold to the original purchaser, from the date of retail purchase by the original end-user purchaser. If a hardware defect arises and a valid claim is received within the warranty period, at its option and to the extent permitted by law, Digital2<sup>™</sup> willi. (1) repair the hardware defect at no charge, using new parts or refurbished parts that are equivalent to new in performance and reliability; or (2) exchange the product with a product that is new or refurbished that is equivalent to new and is functionally equivalent to the original product. This warranty is for replacement for like-items only and does not cover items out of production if the company no longer stocks them. This warranty is not assignable or transferable. Customers are responsible for all replacement shipping charges. Third-party products, such as mobile/handheld devices, or other peripherals interacting with the Product are not covered by this warranty. Digital2<sup>™</sup> is not liable for any 3rd party bundle product(5).

Upon Digital2's replacement or repair of a Product under warranty, the original end-user purchaser will have a remaining warranty of the original warranty period. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Digital2's property. Important: Do not disassemble the Product. Disassembling the Product will void this warranty. Only Digital2" or a party expressly authorized by Digital2" should perform service on this Product.

This warranty only covers technical hardware issues during the warranty period and under normal use conditions. Digital2<sup>™</sup> does not warrant uninterrupted or error-free operation of this Product. This Warranty does not apply to software, environmental, or customer induced damages or circumstances, such as, but not limited to:

- (a) Product has been tampered with, repaired and/or modified by non-authorized personnel;
- (b) Obsolescence:
- (c) Damage (accidental or other) to the Product that is cosmetic, meaning damage that does not impact the operation and functioning of the Product, such as without limitation to rust, change in color, texture or finish, wear and tear, scrapes, dents, cracks. or gradual deterioration;
- (d) Damage to the Product caused by war, terrorism, fire, accident, natural disaster, intentional or accidental misuse, abuse, neglect or improper maintenance, use under abnormal conditions, accidental drops, spills, fire, or power surges:
- (e) Damage to the Product cause by improper installation, connection or malfunction of a peripheral device or connectivity issues (including both hardware and software);
- (f) Fraud, theft, unexplained disappearance or willful act.

TO THE EXTENT PERMITTED BY LAW, THIS WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTES, REMEDIES AND CONDITIONS, WHETHER ORAL, WRITTEN, STATUTORY, EXPRESS OR IMPLIED. AS PERMITTED BY APPLICABLE LAW, Digital<sup>24</sup> SPECIFICALLY DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, HTNESS FOR A PARTICULAR PURPOSE, AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF DIGITAL<sup>24\*</sup> CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES HID TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DEPARTON OF THE EXPRESS WARRANTY AND TO THE REPAIR OR REPLACEMENTED BY DIGITAL<sup>24\*</sup> IN ITS SOLE DISCRETION. NO RESELLER, AGENT, OR EMPLOYEE IS AUTHORIZED TO MAKE ANY MODIFICATION, EXTENSION, OR ADDITION TO THIS WARRANTY. IF ANY TERMIS) IS HELD ILLEGAL OR NORMOROGABLE, THE LEGALITY AND ENFORCES AND TO THE REMAINING TERMS SHALL NOT BE REFECTED.

EXCEPT AS PROVIDED IN THIS WARRANTY AND TO THE MAXIMUM EXTENT PERMITTED BY LAW, Digital?" IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY PREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY, INCLUDING BUT NOT LIMITED TO LOSS OF USE; LOSS OF REVENUE; LOSS OF ACTUAL OR ANTICIPATED PROFITS (INCLUDING LOSS OF PROFITS ON CONTRACTS); LOSS OF THE USE OF MONEY; LOSS OF ANTICIPATED SAWINGS; LOSS OF BUSINESS; LOSS OF POPORTURITY; LOSS OF GOODWILL; LOSS OF REPUTATION; LOSS OF, DAMAGE TO, COMPRENDISE OR CORRUPTION OF DATA, OR ANY INDIRECT OR CONSEQUENTIAL LOSS OR DAMAGE HOWSOEVER CASSED INCLUDING THE REPLACEMENT OF EQUIPMENT AND PROPERTY, ANY COSTS OF RECOVERING, PROGRAMMING OR REPRODUCING ANY PROGRAM OR DATA STORED IN OR USED WITH THE DIGITAL?" PRODUCT AND ANY FAILURE TO MAINTAIN THE CONFIDENTIALITY OF DATA STORED ON THE PRODUCT. THE FORECOME UNITATION SHALL NOT APPLY TO DEATH OR PRESONAL INJURY CLAMPS, OR ANY STATUTIORY LIBITATION FOR INTENTIONAL AND GROSS NEGLIGENT ACTS AND/OR OMISSIONS. DIGITALS" DISCLAMS ANY REPRESENTATION THAT IT WILL BE ABLE TO REPAIR ANY PRODUCT UNDER THIS WARRANTY OR MAKE A PRODUCT EXCHANGE SECULUTION ANY VESRE SOFTWARE OR DATA TO